



NAVODAYA INSTITUTE OF TECHNOLOGY, RAICHUR


DEPARTMENT OF COMPUTER SCIENCE & ENGINEERING

IOT Lab Program - 08

08 Develop a program to detect the gas leakage in the surrounding environment

Components

- Arduino Uno/Nano
- MQ gas sensor module (MQ-2 is a good default)
- Buzzer **or** LED + 220 Ω **or** Relay module (to drive fan/alarm)
- Breadboard + jumper wires
- (Optional) 0.1 μ F cap between A0 and GND for extra noise filtering

 MQ sensors have a heater and draw ~150–200 mA at 5 V. Power the sensor from **5 V** (not 3.3 V) and avoid weak USB hubs.

Wiring

- **Sensor module:** VCC \rightarrow 5V, GND \rightarrow GND, AO \rightarrow A0 (analog), DO (optional) \rightarrow D4
 - **Alarm:** D7 \rightarrow buzzer/LED(or relay IN) \rightarrow GND (LED needs a 220 Ω series resistor)
 - (Relay module: VCC \rightarrow 5V, GND \rightarrow GND; switch your external load via COM/NO)
-

Steps to Do the Experiment

1. **Assemble the circuit** as above.
2. **Warm-up** the MQ sensor: power it for **5–10 minutes** (for quick demos). For best stability, initial “burn-in” can be **24–48 h** when new.
3. **Upload** the Arduino sketch below and open **Serial Monitor @ 115200**.
4. **Observe baseline** analog readings in clean air for ~1–2 minutes; note the average (e.g., 180–260).
5. **Calibrate threshold:** briefly waft a tiny bit of test gas (e.g., an *unlit* lighter near the intake) and note the spike (e.g., 420–700). Set THRESHOLD midway between baseline and spike.

6. **Test alarm:** approach with the same source → buzzer/relay should activate; remove source → alarm clears after hold time.
 7. (Optional) Use the **DO** pin and its onboard potentiometer as a hardware threshold; the code supports both analog and digital modes.
-

📄 Arduino Program (analog smoothing + hysteresis + alarm hold)

/* Gas Leak Detector (MQ-2/MQ-5/MQ-135) with Arduino

- Sensor AO -> A0 (analog), DO -> D4 (optional)
- Alarm (buzzer/LED/relay) -> D7
- Serial at 115200 for live logs

*/

const uint8_t PIN_GAS_AO = A0;

const uint8_t PIN_GAS_DO = 4; // optional digital comparator from module

const uint8_t PIN_ALARM = 7;

const uint16_t SAMPLES = 20; // moving average window

const uint16_t SAMPLE_DELAY_MS = 20;

int THRESHOLD = 380; // set after calibration

int HYST = 20; // hysteresis to avoid chatter (+/-)

unsigned long ALARM_HOLD_MS = 8000;

unsigned long alarmUntil = 0;

bool alarmState = false;

uint16_t readSmoothedAnalog() {

uint32_t sum = 0;

for (uint16_t i = 0; i < SAMPLES; i++) {

sum += analogRead(PIN_GAS_AO);

delay(SAMPLE_DELAY_MS);

}

return sum / SAMPLES;

}

void setAlarm(bool on) {

alarmState = on;

digitalWrite(PIN_ALARM, on ? HIGH : LOW);

}

void setup() {

pinMode(PIN_ALARM, OUTPUT);

pinMode(PIN_GAS_DO, INPUT); // safe even if unused

setAlarm(false);

Serial.begin(115200);

delay(500);

Serial.println(F("Gas Leak Detector - MQ Sensor"));

Serial.println(F("Warm up the sensor for a few minutes before trusting readings..."));

}

void loop() {

// Read analog with smoothing

uint16_t a = readSmoothedAnalog();

```

// Optional digital comparator from module (active LOW on many boards)
int doVal = digitalRead(PIN_GAS_DO);

// Hysteresis logic around THRESHOLD
bool tripAnalog = false;
if (!alarmState && a >= (THRESHOLD + HYST)) tripAnalog = true;
if (alarmState && a >= (THRESHOLD - HYST)) tripAnalog = true;

// Combine analog decision with optional digital comparator
bool trip = tripAnalog || (doVal == LOW); // adjust if your board's DO is active HIGH

unsigned long now = millis();
if (trip) {
    alarmUntil = now + ALARM_HOLD_MS; // latch for a bit
}
setAlarm(now < alarmUntil);

// Logs
Serial.print(F("Analog: ")); Serial.print(a);
Serial.print(F(" DO: ")); Serial.print(doVal);
Serial.print(F(" Threshold: ")); Serial.print(THRESHOLD);
Serial.print(F(" Alarm: ")); Serial.println(alarmState ? F("ON") : F("off"));
}

```

Calibration Tips

- After warm-up in clean air, note baseline (e.g., **220**).
- Expose briefly to target gas and note peak (e.g., **600**).
- Set THRESHOLD \approx (**baseline + peak**) / 2 (here, ~ 410).
- Adjust HYST (10–40) to reduce chattering. Increase SAMPLES for steadier readings (slower but smoother).